

Transmission, disassembling and assembling

ATF cooler and ATF filler tube, removing and installing ⇒ [page 37-54](#)


Planetary gearbox disassembly and assembly, overview ⇒ [page 37-55](#)

Planetary gearbox, disassembling ⇒ [page 37-70](#)

Planetary gearbox, assembling ⇒ [page 37-76](#)

Planetary gearbox adjustments, overview ⇒ [page 37-89](#)

Valve body, removing and installing ⇒ [page 38-36](#)



ATF cooler and ATF filler tube, removing and installing

1 - Banjo bolt

◆ Tightening torque: 35 Nm (26 ft lb)

2 - O-ring

◆ Always replace

3 - ATF cooler

4 - O-ring

◆ Always replace

5 - Transmission housing

6 - ATF dipstick


◆ Checking ATF level ⇒ [page 37-47](#)

7 - ATF filler tube

8 - Bolt

9 - O-ring

◆ Always replace



Planetary gearbox disassembly and assembly, overview

Note:

Disassembling planetary gearbox ⇒ [page 37-70](#) .


Assembling ⇒ [page 37-76](#) .

I - ATF pump to support tube, removing and installing ⇒ [page 37-57](#)

II - Reverse gear clutch -K2- to large sun gear, removing and installing ⇒ [page 37-61](#)

Note:

The small sun wheel (arrow 1) cannot be removed from the planet carrier in transmissions from 01.93 ⇒ [page 00-5](#) .



III - Free wheel and reverse gear brake -B1- , removing and installing ⇒ [page 37-64](#)


Note:

To remove and install free wheel first remove valve body together with plugs ⇒ [page 38-36](#) .

IV - Planet carrier and input gear, removing and installing ⇒ [page 37-67](#)

Note:

- ◆ It is not necessary to remove the input gear (arrow).
- ◆ Removing and installing input gear ⇒ [page 39-8](#) .



I - ATF pump to support tube, removing and installing

⇒ [Overview, page 37-55](#)

Note:

Disassembling planetary gearbox ⇒ [page 37-70](#) .

Assembling ⇒ [page 37-76](#) .

1 - Bolt


- ◆ Qty. 7
- ◆ Tightening torque: 8 Nm (71 in lb) plus an additional $\frac{1}{4}$ -turn (90°)
- ◆ The additional $\frac{1}{4}$ -turn (90°) may be done in several stages

2 - ATF pump with -B2- piston

- ◆ Disassembling and assembling ⇒ [page 38-1](#)

3 - O-ring

- ◆ Always replace
- ◆ Place on ATF pump



4 - Gasket

- ◆ Always replace

5 - Spring cap

- ◆ Qty. 6
- ◆ Install 3 spring caps after installing first outer plate
- ◆ Install 3 spring caps before installing last outer plate


6 - Spring

- ◆ Qty. 3

7 - Corrugated spring washer

8 - Outer plate -B2-

- ◆ Quantity ⇒ [from page 00-3](#)
- ◆ Determining thickness of outer plate ⇒ [page 37-113](#) , 2nd and 4th gear brake -B2-, adjusting



9 - Inner plate -B2-


- ◆ Quantity ⇒ [from page 00-3](#)
- ◆ Before installing, place in in ATF for 15 minutes

10 - Outer plate -B2-

- ◆ Always install outer plates that are 2 mm (0.079 in.) thick
- ◆ Quantity ⇒ [from page 00-3](#)

11 - Outer plate -B2-

- ◆ Fit 3 mm (0.118 in.) thick outer plate to supporting tube



12 - Supporting tube -B2-

◆ For -B2- plate package

◆ Length of -B2-:


with 4 inner plates 72.3 mm
(2.846 in.)

with 5 inner plates 68.6 mm
(2.701 in.)

with 6 inner plates 64.9 mm
(2.555 in.)

◆ Quantity of -B2- inner plates ⇒ [from page 00-3](#)

◆ Insert so that groove engages in wedge of free wheel



II - Reverse gear clutch -K2- to large sun gear, removing and installing

⇒ [Overview, page 37-55](#)

Note:

Disassembling planetary gearbox ⇒ [page 37-70](#) .

Assembling ⇒ [page 37-76](#) .

1 - Reverse gear clutch -K2-


- ◆ Disassembling and assembling ⇒ [page 38-23](#)

2 - Shim

- ◆ Determining thickness ⇒ [page 37-106](#) , Clutch play between -K1- and -K2-, adjusting
- ◆ 1 or 2 shims can be installed

3 - 1st to 3rd gear clutch -K1- with turbine shaft

- ◆ With ball valve (arrow), disassembling and assembling ⇒ [page 38-16](#)
- ◆ Without ball valve (for transmissions from 01.93 ⇒ [page 00-5](#)). Disassembling and assembling ⇒ [page 38-16](#)



4 - Axial needle bearing washer

5 - Axial needle bearing

6 - Axial needle bearing washer

◆ Lugs face toward axial needle bearing

7 - 4th gear clutch -K3- with pump shaft

◆ With ball valve (arrow), disassembling and assembling ⇒ [page 38-26](#)

◆ 4th gear clutch -K3- without ball valve (for transmissions from 01.93 ⇒ [page 00-5](#)), disassembling and assembling ⇒ [page 38-26](#).

8 - Axial needle bearing with washer


◆ Axial needle bearing faces toward small drive shaft

9 - Small drive shaft

10 - Needle bearing

11 - Axial needle bearing

N37-0033



III - Free wheel and reverse gear brake -B1- , removing and installing

⇒ [Overview, page 37-55](#)

Note:

Disassembling planetary gearbox ⇒ [page 37-70](#) .

Assembling ⇒ [page 37-76](#) .

1 - Circlip

- ◆ For supporting tube -B2-

2 - Circlip

- ◆ For free wheel


3 - Free wheel with -B1- piston

- ◆ Before removing free wheel, remove valve body and sealing plugs ⇒ [page 38-36](#)
- ◆ Disassembling and assembling ⇒ [page 38-4](#)

4 - Dished spring

- ◆ Install with convex part facing free wheel

N37 - 0034



N37 - 0034

5 - Pressure plate

- ◆ Install with flat side facing plates
- ◆ Differing plate thickness depending on number of inner plates installed:

Up to transmission build date 16 08 2:


- ◆ With 4 inner plates 7.5 mm (0.295 in.) (an additional 3.7 mm (0.146 in.) shim - 8- is installed)
- ◆ With 5 inner plates 7.5 mm (0.295 in.)

From transmission build date 17 08 2:

- ◆ With 4 inner plates 11.1 mm (0.437 in.)
- ◆ With 5 inner plates 7.5 mm (0.295 in.)

Transmissions from 01.93:

- ◆ With 4 inner plates 13.5 mm (0.531 in.)
- ◆ With 5 inner plates 10.5 mm (0.413 in.)
- ◆ Quantity of -B1- inner plates ⇒ [from page 00-3](#)



N37 - 0034

6 - Inner plate, -B1-


- ◆ Quantity ⇒ [from page 00-3](#)
- ◆ Before installing place in ATF for 15 minutes

7 - Outer plate, -B1-

- ◆ Quantity ⇒ [from page 00-3](#)

8 - Shim

- ◆ Determining thickness ⇒ [page 37-98](#) , Reverse gear brake -B1-, adjusting
- ◆ Additional 3.7 mm (0.146 in.) shim for -B1- with 4 inner plates, up to transmission build date 16 08 2 item - 5 -



N37 - 0031

IV - Planet carrier and input gear, removing and installing

⇒ [Overview, page 37-55](#)

Note:

Disassembling planetary gearbox ⇒ [page 37-70](#)

Assembling ⇒ [page 37-76](#) .

1 - Planet carrier


- ◆ Modified ratios for transmissions from 01.93 ⇒ [page 00-5](#)
- ◆ Small sun gear cannot be removed in transmissions from 01.93
- ◆ Adjusting ⇒ [page 37-90](#)

2 - O-ring

- ◆ Always replace
- ◆ Insert in planet carrier

3 - Axial needle bearing washer

4 - Axial needle bearing



N37 - 0031

5 - Axial needle bearing washer

- ◆ Install smooth side in input gear

6 - Transmission housing

7 - Input gear

- ◆ Do not remove to disassemble planetary gearbox
- ◆ Removing and installing input gear or axial needle bearing for planet carrier ⇒ [page 39-8](#)


8 - Planet carrier shim

- ◆ Determining thickness ⇒ [page 37-90](#) , Planet carrier, adjusting

9 - Washer

10 - Bolt

- ◆ Tightening torque: 30 Nm (22 ft lb)
- ◆ For small input shaft



N37 - 0031

11 - Spacer bush

◆ Qty. 7

◆ Clip into gasket

12 - Gasket

◆ Always replace

13 - Cover**14 - Bolt**

◆ Tightening torque: 8 Nm (71 in lb)


Planetary gearbox, disassembling and assembling

Disassembling

- Seal ATF cooler connections.
- Drain ATF.

ATF can be removed using VAG 1358A extraction system with VAG 1358A/1 probe, or EZ1 fluid evacuator.

- Remove torque converter.
- Secure transmission to assembly support with bolts -1- and -2-.



A



A

- Remove transmission housing cover with gasket (arrow).


- Remove sump.

- Remove ATF screen.




- Remove valve body.

⇒ [page 38-36](#)




- Remove sealing plugs for -B1-.



To remove ATF pump:


- Remove ATF pump bolts.



A


- Screw bolts -A- (M8) into tapped holes in ATF pump.

- Press ATF pump off transmission by turning bolts -A- evenly.




A

- Take out all clutches with supporting tube, -B2- plates, springs and spring caps together.




A

- Insert screwdriver through hole of large drive shaft and large sun gear to loosen and tighten bolt for small drive shaft.




A


- Loosen small drive shaft bolt (arrow).
- Remove small drive shaft bolt, washer and shim.
 - ◆ Planet carrier axial needle bearing remains in transmission/input gear
- Pull out small drive shaft.



- A - Pull out large drive shaft (arrow).




- A - Pull out large sun gear (arrow).



A

- Remove supporting tube circlip -a- and free wheel circlip -b-.
- Remove free wheel from transmission housing by pulling on free wheel retaining wedge (arrow) with pliers.




A

- Pull out planet carrier with dished spring.
- Remove reverse gear brake -B1- plates.

Note:

- ◆ *It is not necessary to remove input gear to disassemble the planetary gearbox. Removing and installing input gear ⇒ [page 39-8](#) .*
- ◆ *Assembling planetary gearbox ⇒ [page 37-76](#) .*

Planetary gearbox, assembling



A

- Install axial needle bearing with washer onto input gear.

1 - Axial needle bearing washer


2 - Axial needle bearing

3 - Axial needle bearing washer

- Install smooth side into input

4 - Input gear

(Installed in transmission housing ⇒ [page 37-55](#))




A

- Install O-ring in planet carrier.

Note:

After replacing planet carrier, adjust ⇒ [page 37-90](#) .



A

- Install washer and axial needle bearing into planet carrier.

1 - Axial needle bearing

◆ Transmissions up to 12.92: outer diameter 41.0 mm (1.61 in.) ⇒ [page 00-3](#)


◆ Transmissions from 01.93: outer diameter 39.1 mm (1.54 in.) ⇒ [page 00-5](#)

2 - Axial needle bearing washer

3 - Small sun gear

◆ Cannot be removed for transmissions from 01.93 ⇒ [page 00-5](#)

4 - Planet carrier




A

- Install planet carrier into input gear.

- Center washer and axial needle bearing in small sun gear.

- Install inner and outer -B1- plates.
- Install pressure plate with flat side facing plates.

Thickness of pressure plate varies according to number of plates ⇒ [page 37-65](#) .



A


- Install dished washer with convex side facing toward free wheel.

Note:

When replacing:


- ◆ *Transmission housing*
- ◆ *Free wheel*
- ◆ *Piston for reverse gear brake -B1-*
- ◆ *or plates*

Then adjust -B1-, ⇒ [page 37-98](#) .




A

- Preload free wheel rollers with 3267 assembly ring and install free wheel.



A

- Install circlip -b- for free wheel and circlip -a- for supporting tube.
- Install so that circlip gaps are over free wheel retaining wedge (arrow).
- Carry out check measurement of -B1- ⇒ [page 37-105](#) .



A


- Install washer with axial needle bearing in large sun gear.

1 - Axial needle bearing

2 - Washer with shoulder

- Install with smooth side facing axial needle bearing


3 - Large sun gear




A

- Install large sun gear with bearing.


- Center both washers with axial needle bearing between sun gears.



- A - Install axial needle bearing and needle bearing in large drive shaft.




- A - Install large drive shaft with bearing.



A

- Install small drive shaft.




A

- Install small drive shaft bolt -1- with washer -2- and shim -3-.
 - ◆ Tightening torque: 30 Nm (22 ft lb)

Note:

- ◆ *Install shim -3- onto small drive shaft shoulder (arrow).*
- ◆ *Determining shim thickness ⇒ [page 37-90](#) , Planet carrier, adjusting.*
- Carry out planet carrier check measurement.

⇒ [page 37-97](#) .



A

- Install axial needle bearing with washers in 4th gear clutch -K3-.

1 - Axial needle bearing washer

2 - Axial needle bearing


3 - Axial needle bearing washer

- Install with smooth side facing -K3-.

4 - 3rd and 4th gear clutch -K3-

Note:

Make sure that piston rings seat correctly.



A


- Install axial needle bearing with washer on 4th gear clutch -K3-.

1 - Axial needle bearing with washer

- Moisten axial needle bearing washer with ATF so that bearing -1-, while installing, sticks to -K3-.

- Install bearing washer on -K3-.


2 - 3rd and 4th gear clutch -K3-



A

- Install 3rd and 4th gear clutch -K3-.

◆ Transmissions from 01.93: -K3- clutch operates only 4th gear ⇒ [page 00-5](#)




A

- Install shims -a- in -K1-.

Notes:


- ◆ Re-measure shim when replacing -K1-, -K2- or ATF pump ⇒ [page 37-106](#), Clutch play between -K1- and -K2-, adjusting.
- ◆ 1 or 2 shims can be installed.



A


- Install 1st to 3rd gear clutch -K1-.

- Install reverse gear clutch -K2-.




A

- Install supporting tube for plate set -B2- (arrow) so that supporting tube groove engages in free wheel wedge.



A

- Install -B2- plates as follows:
 - First install a 3 mm (0.118 in.) thick outer plate.
 - Install three spring caps in outer plate.
 - Install compression springs (arrows).
 - Install all but the last outer plate.



A

- Before installing the last outer plate, install three spring caps onto compression springs.


Note:

When replacing:

- ◆ *Supporting tube*
- ◆ *the ATF pump*
- ◆ *or the plates*

... the 2nd and 4th gear brakes -B2- are to be adjusted, ⇒ [page 37-113](#) .

- Replace corrugated washer.
- Replace ATF pump seal.
- Install O-ring on ATF pump.




A

- Install ATF pump.
- Tighten bolts evenly, alternating cross-wise.
 - ◆ Tightening torque: 8 Nm (71 in lb) plus an additional $\frac{1}{4}$ -turn (90°)
 - ◆ Additional $\frac{1}{4}$ -turn can be done in several stages.

Note:

- ◆ *Make sure that the O-ring is not damaged.*
- Carry out check measurement of clutch play ⇒ [page 37-112](#) .
- Install sealing plugs, valve body and oil pan ⇒ [page 38-36](#) .
- Install cover with gasket and spacer bushings.



Planetary gearbox adjustments, overview

I - Reverse gear brake -B1-

- ◆ A = Shim
- ◆ Determining thickness ⇒ [Reverse gear brake -B1-, adjusting, page 37-98](#)

II - 2nd and 4th gear brake -B2-


- ◆ B = Outer plate
- ◆ Determining thickness ⇒ [page 37-113](#) ,
2nd and 4th gear brake -B2-, adjusting

III - Planet carrier

- ◆ C = Shim
- ◆ Determining thickness ⇒ [page 37-90](#) ,
Planet carrier, adjusting

IV - Clutch play

- ◆ D = Shim
- ◆ Determining thickness ⇒ [page 37-106](#) ,
Clutch play between -K1- and -K2-,
adjusting



Planet carrier, adjusting

Overview of components to adjust planet carrier

- When adjusting planet carrier, install components in transmission housing without shim - 17 -.

1 - Transmission housing

- ◆ With input gear and axial needle bearing
- ◆ Axial needle bearing remains in input gear
- ◆ Damaged axial needle bearing ⇒ [page39-8](#), Input gear, removing and installing


2 - Axial needle bearing washer

- ◆ Insert smooth side in input gear

3 - Axial needle bearing

4 - Axial needle bearing washer

N37 - 0035



5 - O-ring

- ◆ Insert into planet carrier ⇒ [page 37-76](#) , Planetary gearbox, assembling

6 - Planet carrier

7 - Small sun gear

- ◆ Cannot be removed from planet carrier in transmissions from 01.93 ⇒ [page 00-5](#)

8 - Washer

9 - Axial needle bearing


10 - Large sun gear

11 - Washer

- ◆ Insert into large sun gear ⇒ [page 37-76](#) , Planetary gearbox, assembling

12 - Axial needle bearing

13 - Large drive shaft



14 - Axial needle bearing

15 - Needle bearing

16 - Small drive shaft

17 - Shim


◆ Do not install in planet carrier when adjusting

18 - Washer

19 - Small drive shaft bolt

◆ Tightening torque: 30 Nm (22 ft lb)


N37 - 0035



A Determining shim -A- thickness


- Install all components to adjust planet carrier in transmission housing.

⇒ [page 37-90](#) , items - 2 - through - 16 - .




A

- Insert screwdriver through hole of large drive shaft and large sun gear to loosen and tighten bolt for small drive shaft.



- A
- Install small input shaft bolt -1- with washer -2-, but without shim.
 - ◆ Tightening torque: 30 Nm (22 ft lb)



- A
- Set up dial indicator so that top of gauge is positioned on center of bolt head with 1 mm preload.
 - Zero dial gauge.
 - Move small input shaft up and take measurement.
 - ◆ Example: measurement = 2.00 mm
 - Specify thickness of shim according to table and determine Part No. from parts catalog microfiche.

Table of shims

Dial indicator measurement - mm	Shim thickness - mm
1.26 - 1.35	1.0
1.36 - 1.45	1.1
1.46 - 1.55	1.2
1.56 - 1.65	1.3
1.66 - 1.75	1.4
1.76 - 1.85	1.5
1.86 - 1.95	1.6
1.96 - 2.05	1.7
2.06 - 2.15	1.8
2.16 - 2.25	1.9
2.26 - 2.35	2.0
2.36 - 2.45	2.1
2.46 - 2.55	2.2
2.56 - 2.65	2.3
2.66 - 2.75	2.4

2.76 - 2.85

2.5

2.86 - 2.95

2.6

2.96 - 3.05

2.7

3.06 - 3.15

2.8

3.16 - 3.25


2.9

Example:


Measurement = 2.00 mm:

- Insert 1.7 mm shim.
- Remove small input shaft bolt.
- ▲ - Install correct shim -3- on small input shaft (arrow).
- Tighten small input shaft bolt -1- with washer -2-.
 - ◆ Tightening torque: 30 Nm (22 ft lb)
- Carry out planet carrier check measurement.

⇒ [page 37-97](#) .



Planet carrier check measurement



A


- Insert dial indicator in VW 382/7 measuring bar and place the tip on the small input shaft bolt.
- Move small input shaft up and down and measure axial play on dial indicator.

Specifications:

- ◆ min. = 0.23 mm (0.0091 in.)
- ◆ max. = 0.37 mm (0.0146 in.)

Note:

If the planet carrier has been adjusted with reverse gear brake -B1- and free wheel removed, then install reverse gear brake -B1- before installing planet carrier ⇒ [Planetary gearbox, assembling, page 37-76](#) .



Reverse gear brake -B1-, adjusting

Overview of components to adjust reverse gear brake -B1-

1 - Transmission housing

2 - Shim


- ◆ Up to transmission build date 16 08 2:
additional 3.7 mm (0.146 in.) shim for -B1-
with 4 inner plates item -5-

3 - Outer plate -B1-

- ◆ Quantity ⇒ [from page 00-3](#)

4 - Inner plate -B1-

- ◆ Quantity ⇒ [from page 00-3](#)



5 - Pressure plate -B1-

- ◆ Install with flat side facing plates
- ◆ Differing thicknesses depending on number of inner plates installed:

Up to transmission build date 16 08 2:


- ◆ With 4 inner plates 7.5 mm (0.295 in.) (an additional 3.7 mm (0.146 in.) shim - 8- is installed)
- ◆ With 5 inner plates 7.5 mm (0.295 in.)

From transmission build date 17 08 2:

- ◆ With 4 inner plates 11.1 mm (0.437 in.)
- ◆ With 5 inner plates 7.5 mm (0.295 in.)

Transmissions from 01.93:

- ◆ With 4 inner plates 13.5 mm (0.531 in.)
- ◆ With 5 inner plates 10.5 mm (0.413 in.)
- ◆ Quantity of -B1- inner plates ⇒ [from page 00-3](#)



6 - Dished washer


- ◆ Convex side faces towards free wheel

7 - Free wheel with -B1- piston

Note:

Before removing or installing free wheel remove valve body and take out sealing plugs ⇒ [page 38-36](#).

8 - Circlip



A Determining shim -A- thickness

Shim thickness is determined by gap -x- and shim is selected from table
 ⇒ [page 37-104](#) .

$$\text{Gap } x = k + \frac{1}{2} - m$$

A - Shim


x - Gap

l - Position of piston in free wheel

m - Height of plate set including thrust plate

K - Constant = 26.8 mm

◆ Constant is determined by installation height in transmission housing and is not adjustable.




Calculating "I":



- Press piston in direction of arrows as far as stop.
- Place straightedge -A- onto outer race of free wheel.
- Measure to inner edge of piston with depth gauge -B-.

Example:

Measurement	=	51.8 mm
- Straightedge height	=	- 48.2 mm
Calculated dimension "I"	=	3.6 mm



Calculating "m":

A

- Place straightedge "A" on thrust plate.
- Compress set of plates including pressure plate in direction of arrows and measure the thickness of plate set with depth gauge "B".

Example:

Measurement	=	73.5 mm
- Straightedge height	=	- 48.2 mm
Calculated dimension "m"	=	25.3 mm

$$= 26.8 + \frac{3.6}{2} - 25.3 = 3.3 \text{ mm}$$

$$= 26.8 + \frac{3.6}{2} - 25.3 = 3.3 \text{ mm}$$

- Determine size of shims according to table.

Table of shims

Gap "x" - mm	Shim thickness - mm
2.36 - 2.45	1.0
2.46 - 2.55	1.1
2.56 - 2.65	1.2
2.66 - 2.75	1.3
2.76 - 2.85	1.4
2.86 - 2.95	1.5
2.96 - 3.05	1.6
3.06 - 3.15	1.7
3.16 - 3.25	1.8
3.26 - 3.35	1.9
3.36 - 3.45	1.0 + 1.0
3.46 - 3.55	1.0 + 1.1
3.56 - 3.65	1.1 + 1.1
3.66 - 3.75	1.1 + 1.2
3.76 - 3.85	1.2 + 1.2
3.86 - 3.95	1.2 + 1.3

3.96 - 4.05 1.3 + 1.3


4.06 - 4.15 1.3 + 1.4

4.16 - 4.25 1.4 + 1.4

- Determine thickness of shims according to table and determine Part No. from parts catalog microfiche.
- After determining shim for -B1- carry out check measurement ⇒ [page 37-105](#) .

Reverse gear brake -B1- check measurement

- Install parts up to free wheel and secure with circlip ⇒ [Planetary gearbox, assembling, page 37-76](#) .




A

- Measure clearance between plates with feeler gauge -A-.

Specifications:

- ◆ minimum = 1.20 mm
- ◆ maximum = 1.80 mm



Clutch play between -K1- and -K2-, adjusting

- To adjust clutch play install components without shim - 8 - ⇒ [Planetary gearbox, assembling, page 37-76](#) .

1 - Transmission housing

2 - Axial needle bearing with washer

- ◆ Axial needle bearing faces towards small input shaft


- ◆ Washer faces toward -K3-

3 - 3rd and 4th gear clutch -K3- with pump shaft

- ◆ On transmissions from 01.93 the -K3- clutch operates only 4th gear ⇒ [page 00-5](#)

4 - Axial needle bearing washer

- ◆ Lugs face toward axial needle bearing



5 - Axial needle bearing

6 - Axial needle bearing washer


7 - 1st to 3rd gear clutch -K1- with turbine shaft

8 - Shim

◆ Do not install when adjusting clutch play

◆ 1 or 2 shims may be installed to achieve correct thickness

9 - Reverse gear clutch -K2-



Determining shim -A- thickness

A - Shim

1 - ATF pump

2 - Reverse gear clutch -K2-

3 - 1st to 3rd gear clutch -K1-

4 - 4th gear clutch -K3-


Note:

On transmissions from 01.93, clutch -K3- operates only 4th gear ⇒ [page 00-5](#) .

- Calculating thickness of shim. Determine gap "x" and calculate shim thickness.

$$\text{Gap } x = a - b$$

Calculating "a":




A

- Place straightedge -A- onto transmission housing.
- Press -K1- down in direction of arrow and measure distance into -K1- with depth gauge -B-.

Example:

Measurement 1 = 88.5 mm



A


- Measure with depth gauge -B- to pump flange on transmission housing.

Example:

Measurement 2 = 34.3 mm

Measurement 1	=	88.5 mm
- Measurement 2	=	- 34.3 mm
Calculated dimension "a"	=	54.2 mm

= Dimension measured from pump flange/transmission housing into -K1-.



Calculating "b":

A

- Place straightedge -B- onto stator support (arrow) and measure with depth gauge -A- to gasket of pump flange.

Example:

Measurement	=	70.5 mm
- Straightedge height	=	- 19.5 mm
Calculated dimension "b"	=	51.0 mm

$$\text{Gap } x = a - b$$

$$= 54.2 - 51.0 = 3.2 \text{ mm}$$

- Determine shim size according to table.


Table of shims

Gap "x" - mm	Shim thickness - mm
- 2.54	1.4
2.55 - 3.09	1 + 1
3.10 - 3.49	1.2 + 1.2
3.50 - 3.89	1.4 + 1.4
3.90 - 4.29	1.6 + 1.6
4.30 - 4.69	1.8 + 1.8
4.70 - 5.04	1.2 + 1.2 + 1.6
5.05 - 5.25	1.2 + 1.2 + 1.8

- Determine thickness of shims according to table and determine Part No. from parts catalog microfiche.
- Carry out clutch play check measurement after installing ATF pump.


Check measurement (clutch play)

- The clutch play cannot be measured until the ATF pump has been installed.
- Attach dial indicator holder to transmission housing and place on turbine shaft with a 1 mm preload.
- Move turbine shaft up and down and read axial play on dial indicator gauge.



Specifications:

- ◆ minimum = 0.5 mm (0.020 in.)
- ◆ maximum = 1.2 mm (0.047 in.)



2nd and 4th gear brake -B2-, adjusting

- Install components to adjust 2nd and 4th gear brake -B2- but without corrugated washer - 11 - and last outer plate - 10 - ⇒ [Planetary gearbox, assembling, page 37-76](#) .

1 - Transmission housing

2 - Circlip

- ◆ For supporting tube

3 - Supporting tube -B2-

- ◆ Length of -B2-:


4 inner plates 72.3 mm
(2.847 in.)

5 inner plates 68.6 mm
(2.701 in.)

6 inner plates 64.9 mm
(2.555 in.)

- ◆ Quantity inner plates -B2- ⇒ [from page 00-3](#)

- ◆ Insert so that notch locates on free wheel wedge



4 - Outer plate -B2-

- ◆ 3 mm thick

5 - Spring cap

- ◆ Install after installing first outer plate

6 - Outer plate -B2-

- ◆ Always install 2 mm thick outer plates
- ◆ Quantity ⇒ [from page 00-3](#)


7 - Inner plate -B2-

- ◆ Quantity ⇒ [from page 00-3](#)

8 - Spring

9 - Spring cap

- ◆ Install before installing last outer plate




10 - Outer plate -B2-

- ◆ Do not install when adjusting -B2-
- ◆ 2 outer plates can be installed.

11 - Corrugated washer

- ◆ Do not install when adjusting -B2-



Calculating thickness of last outer plate -A-


The thickness of the outer plate is determined by gap "x" and is selected from table ⇒ [page 37-118](#) .

$$\text{Gap } x = a - b - 3.6 \text{ mm}$$

A - Outer plate

Note:

First outer plate (arrow) is always 3 mm thick.



A

Calculating "a":

- Measure from pump flange/transmission housing to the last inner plate with depth gauge "A". Press inner plate down (in direction of arrow) for this step.


Example:

Measurement "a" = 30.2 mm

Calculating "b":

A

- Place straightedge "B" onto stator support (-arrow-) and measure with depth gauge "A" to gasket of pump flange.



Example:

Measurement	=	40.1 mm
- Straightedge height	=	- 19.5 mm
Calculated size "b"	=	20.6 mm

$$\text{Gap } x = a - b - 3.6 \text{ mm}$$

$$= 30.2 - 20.6 = 6.00 \text{ mm}$$


- Determine thickness of outer plate according to table:

Table of plates

Gap "x" - mm	Plate thickness - mm
4.25 - 4.49	2.75
4.50 - 4.74	3.00
4.75 - 4.99	3.25
5.00 - 5.24	3.50
5.25 - 5.49	3.75
5.50 - 5.74	2.00 + 2.00
5.75 - 5.99	2.00 + 2.25
6.00 - 6.24	2.25 + 2.25
6.25 - 6.49	2.25 + 2.50
6.50 - 6.74	2.50 + 2.50
6.75 - 7.00	2.50 + 2.75

- Determine thickness of outer plate according to table and determine Part No. from parts catalog microfiche.

- ◆ Two outer plates can be installed if necessary to achieve the specified thickness.



V38 - 0690

ATF pump, disassembling and assembling

1 - Piston ring

◆ Check that ring is correctly located ⇒ [Fig. 1](#)

◆ Installing ⇒ [Fig. 2](#)

2 - Piston ring

◆ Check that ring is correctly located ⇒ [Fig. 1](#)

◆ Installing ⇒ [Fig. 2](#)

3 - Piston ring

◆ Check that ring is correctly located ⇒ [Fig. 1](#)

◆ Installing ⇒ [Fig. 2](#)


4 - Thrust washer

5 - Piston

◆ Sealing lips are vulcanized to piston

◆ Moisten sealing lips with ATF before installing

◆ Turn piston slightly while installing



V38 - 0690

6 - Bolt

- ◆ Tightening torque: 10 Nm (7 ft lb)
plus additional $\frac{1}{8}$ -turn (45°)

7 - Stator support**8 - Outer gear**

- ◆ Manufacturer's marking faces stator support
- ◆ If outer gear is incorrectly installed, ATF pump may not operate freely in the installed position

9 - Inner gear


- ◆ Larger groove faces stator support

10 - Housing for ATF pump**11 - O-ring**

- ◆ Always replace

12 - Torque converter oil seal


- ◆ Removing and installing ⇒ [page 32-3](#)



A

Fig. 1 Checking that piston rings are correctly located


- Make sure that ends of piston rings are hooked together.



A

Fig. 2 Fitting and hooking ends of piston ring together

- Place piston ring in groove.
- To hook ends together press sides of ring in and guide ends over one another.
- Do not twist piston ring out of groove on one side.



Final drive, disassembling and assembling

Repair overview

1 - Planetary gear


- ◆ Disassembling and assembling ⇒ [page 37-55](#)

2 - Input gear

- ◆ Removing and installing ⇒ [page 39-8](#)
- ◆ Adjusting ⇒ [page 39-49](#)
- ◆ Adjusting final drive (overview) ⇒ [page 39-42](#)

Note:

Repairs on the input gear can be carried out only after the component parts of the planetary gear have been removed.




3 - Drive pinion

- ◆ Removing and installing ⇒ [page 39-14](#)
- ◆ Adjusting ⇒ [page 39-45](#)
- ◆ Adjusting final drive (overview) ⇒ [page 39-42](#)

4 - Differential

- ◆ Removing and installing ⇒ [page 39-23](#)
- ◆ Disassembling and assembling ⇒ [page 39-34](#)
- ◆ Adjusting ⇒ [page 39-52](#)
- ◆ Adjusting final drive (overview) ⇒ [page 39-42](#)



Input gear, removing and installing

Note:

Drive pinion and differential do not need to be removed.

1 - Socket-head fastener

- ◆ Tightening torque: 250 Nm (184 ft lb)
- ◆ Engage parking lock to remove and install
- ◆ Use 22 mm hex wrench
- ◆ Before installing socket head fastener insert axial needle bearing - 7 -


2 - Dished washer

- ◆ Curved side faces socket head fastener

3 - Shim

- ◆ Determining thickness ⇒ [page 39-49](#) , Input gear, adjusting

V39-1371



4 - Tapered roller bearing inner race

- ◆ Install so that lugs engage in groove of tapered roller bearing inner race - 9 - ⇒ [Fig. 3](#)
- ◆ Installation position ⇒ [Fig. 4](#)
- ◆ After measuring thickness of shim, fit onto input gear with AMV 185 101 A1 thread locking fluid

5 - Tapered roller bearing outer race


- ◆ Drive out with drift
- ◆ Drive in with tool 30-205
- ◆ Install with AMV 185 101 A1 locking fluid

6 - Transmission housing

7 - Axial needle bearing

- ◆ Install with flat side facing input gear
- ◆ Insert into input gear before installing socket-head fastener - 1 -

V39-1371



8 - Tapered roller bearing outer race

- ◆ Drive out with drift
- ◆ Drive in with 30-205 and appropriately long drift
- ◆ Install with thread locking fluid AMV 185 101 A1

9 - Tapered roller bearing inner race


- ◆ Pulling off ⇒ [Fig. 1](#)
- ◆ Pressing on ⇒ [Fig. 2](#)
- ◆ Installation position ⇒ [Fig. 4](#)
- ◆ Install with AMV 185 101 A1 locking fluid

10 - Input gear

- ◆ With impulse wheel for Vehicle Speed Sensor (VSS) -G68-
- ◆ Number of teeth ⇒ [page 00-3](#) , Technical data
- ◆ Adjusting ⇒ [page 39-49](#)
- ◆ If signs of damage exist, always replace input gear and output gear together
- ◆ Removing ⇒ [Fig. 5](#)

Note:


*If input gear is replaced, adjust planet carrier ⇒
[page 37-8.](#)*



A

Fig. 1 Pulling off tapered roller bearing inner race

- Place press piece on input gear.




A

Fig. 2 Pressing on tapered roller bearing inner race

Note:


A press piece must be placed below the hub of the input gear to avoid damaging the input gear.



A

Fig. 3 Installing tapered roller bearing inner race

- Install tapered roller bearing inner race so that the lugs of the inner race engage in the grooves of the opposite inner race (arrow) ⇒ [Fig. 4](#).



A

Fig. 4 Installation position of tapered roller bearing inner race

- Lug (arrow) must engage in groove of the opposite inner race.

Note:

Tapered roller bearings without lugs can also be installed.





Fig. 5 Removing input gear

- Install socket-head fastener without dished washer, shim and axial needle bearing, just far enough so that gap -a- remains between socket-head fastener and tapered roller bearing inner race.
 - ◆ Gap -a- = approx. 3 mm (0.118 in.)
- Drive out input gear with VW 771 as far as the stop of the tapered roller bearing inner race.
- Remove VW 771 and remove input gear.



Drive pinion, removing and installing

Note:

To remove the drive pinion, the selector shaft must be removed after taking out the parking lock ⇒ [page 38-45](#) , Parking lock, disassembling and assembling.


1 - Drive pinion

- ◆ Number of teeth ⇒ [from page 00-3](#) , Technical data
- ◆ Adjusting ⇒ [page 39-45](#)
- ◆ Removing ⇒ [Fig. 8](#)

2 - Transmission housing

3 - Screw

- ◆ Tightening torque: 12 Nm (9 ft lb)
- ◆ Remove screw before removing or installing bearing supporting ring - 12 -
- ◆ Install with AKD45600001 sealing compound



4 - Hex nut

- ◆ Tightening torque: 250 Nm (184 ft lb)
- ◆ Engage parking lock to remove or install
- ◆ Secure with drift

5 - Output gear

- ◆ Number of teeth ⇒ [from page 00-3](#) , Technical data
- ◆ Pulling off ⇒ [Fig. 1](#)
- ◆ If signs of damage exist, always replace input gear and output gear together

6 - Tapered roller bearing inner race

- ◆ Pulling off ⇒ [Fig. 2](#)
- ◆ Pressing on ⇒ [Fig. 3](#)


7 - Tapered roller bearing outer race

- ◆ Drive out with drift
- ◆ Pressing in ⇒ [Fig. 4](#)

8 - Bolt

- ◆ M6: 14 Nm (10 ft lb)
- ◆ M8: 25 Nm (18 ft lb)

9 - Bearing cap



10 - Shim


- ◆ Determining thickness ⇒ [page 39-45](#) , Drive pinion, adjusting

11 - Parking lock gear

- ◆ Rounded side faces teeth of drive

12 - Bearing support ring

- ◆ Tightening torque: 200 Nm (148 ft lb)
- ◆ Remove screw - 3 - before removing or installing bearing support ring
- ◆ Removing or installing ⇒ [Fig. 5](#)
- ◆ Bearing support ring cannot be unscrewed until the selector shaft has been removed ⇒ [page 38-45](#) , Parking lock, disassembling and assembling
- ◆ Install bearing supporting ring carefully. Sealing lip and spring must not be damaged.
- ◆ Supporting ring with seal ⇒ [Fig. 6](#)



13 - O-ring

- ◆ Always replace
- ◆ Place onto bearing support ring - 12 -

14 - Oil seal for drive pinion


- ◆ Remove with screwdriver
- ◆ Installation position ⇒ [Fig. 6](#)
- ◆ Driving in ⇒ [Fig. 7](#)

15 - Tapered roller bearing outer race

- ◆ Driving in ⇒ [Fig. 9](#)

16 - Tapered roller bearing inner race


- ◆ Drive off with drift
- ◆ Pressing on ⇒ [Fig. 10](#)



A

Fig. 1 Pulling off output gear


A - Kukko 20-10 and Matra V 172 pulling hooks



A


Fig. 2 Pulling off tapered roller bearing inner race

- Place press piece onto collar of output gear.




A

Fig. 3 Pressing on tapered roller bearing inner race



A

Fig. 4 Pressing in tapered roller bearing outer race



A


Fig. 5 Removing and installing bearing supporting ring

A - Torque wrench

- Tighten bearing supporting ring.

◆ Tightening torque: 200 Nm (148 ft lb)

- Secure with locking screw. Install screw with thread sealing compound AKD45600001.




A

Fig. 6 Bearing supporting ring with seal for drive pinion

Installation position of seal:


◆ Open side (arrow) faces toward tapered roller bearing outer race



A


Fig. 7 Driving in drive pinion oil seal

- Install oil seal so that sealing lip faces special tool 30-204.



A


Fig. 8 Removing drive pinion



A


Fig. 9 Driving in tapered roller bearing outer race

- Install drive pinion with tapered roller bearing inner race, then drive in outer race.



A

Fig. 10 Pressing on tapered roller bearing inner race



Differential, removing and installing

Note:

- ◆ If tapered roller bearings are to be re-used, mark the adjusting ring ⇒ [Fig. 2](#)
- ◆ The drive pinion does not need to be removed for removing and installing the differential.


1 - Transmission housing

2 - Speedometer drive

- ◆ With marking for oil level indication ⇒ [Fig. 7](#)

3 - Output shaft/drive flange

- ◆ Install thread facing drive flange
- ◆ Remove before taking out differential
- ◆ First adjust differential before installing



4 - O-ring


- ◆ Always replace

5 - Adjusting ring

- ◆ Removing ⇒ [Fig. 3](#)
- ◆ If used bearings are re-installed, mark installation position and line up on marking again when installing ⇒ [Fig. 2](#)
- ◆ If new bearings are installed, pay attention to setting instructions ⇒ [page 39-52](#) , Differential, adjusting

6 - Oil seal for drive flange

- ◆ Before installing, pack space between sealing lips with multi-purpose grease
- ◆ Can be replaced with transmission installed ⇒ [page 39-2](#)
- ◆ Remove with VW 681
- ◆ Driving in ⇒ [Fig. 1](#)



7 - Tapered ring

- ◆ Shoulder faces thrust washer

8 - Thrust washer

- ◆ Place over compression spring

9 - Compression spring

10 - Drive flange

- ◆ Install with tapered ring, thrust washer and compression spring

- ◆ Remove before taking out inner circlip on bevel gear

- ◆ Removing and installing ⇒ [Fig. 4](#)

11 - Dished washer


12 - Circlip

13 - Cover

14 - Locking element

15 - Screw

- ◆ Tightening torque: 12 Nm (9 ft lb)



16 - Cover

17 - Circlip

18 - Dished washer

19 - Drive flange

◆ Install with tapered ring, thrust washer and compression spring

◆ Remove before taking out inner circlip on bevel gear

◆ Removing and installing ⇒ [Fig. 4](#)


20 - Compression spring

21 - Thrust washer

◆ Place over compression spring

22 - Tapered ring

◆ Shoulder faces thrust washer



23 - Oil seal for drive flange


- ◆ Before installing, pack space between sealing lips with multi-purpose grease
- ◆ Can be replaced with transmission installed ⇒ [page 39-2](#)
- ◆ Remove with VW 681
- ◆ Driving in ⇒ [Fig. 1](#)

24 - Bearing body

- ◆ Tightening torque: 150 Nm (111 ft lb)
- ◆ When installing new bearing, pay attention to setting instructions ⇒ [page 39-52](#), Differential, adjusting
- ◆ Remove with tool 3155
- ◆ Installing ⇒ [Fig. 5](#)

25 - O-ring

- ◆ Always replace



26 - Output shaft/drive flange

- ◆ Install thread facing drive flange
- ◆ Before removing, take out differential
- ◆ First adjust differential before installing

27 - Differential

- ◆ Disassembling and assembling ⇒ [page 39-34](#)
- ◆ Before removing differential, take out bearing body, adjusting ring and output shafts


28 - Screw

- ◆ Tightening torque: 12 Nm (9 ft lb)

29 - Locking element

30 - Circlip

- ◆ First remove drive flange before removing circlip
- ◆ Removing and installing ⇒ [Fig. 6](#)



31 - Circlip

- ◆ First remove drive flange before removing circlip
- ◆ Removing and installing ⇒ [Fig. 6](#)

32 - Seal

- ◆ Always replace

33 - Cover


- ◆ For differential

34 - Screw


- ◆ Tightening torque: 28 Nm (21 ft lb)
- ◆ Install with thread locking fluid AMV 185 101 A1

Note:

After adjusting tapered roller bearings, secure bearing body and adjusting ring.




A Fig. 1 Driving in drive flange oil seal up to stop




A Fig. 2 Marking adjusting ring

- If used bearings are re-installed, mark installation position (arrow) and use marking to position adjusting ring when installing.




A Fig. 3 Removing adjusting ring



A Fig. 4 Removing and installing drive flange

Note:


Drive flange can also be removed with VW 391.



A

Fig. 5 Installing differential


- Screw in bearing body as far as stop, then tighten.
 - ◆ Tightening torque: 150 Nm (111 ft lb)



A

Fig. 6 Installing circlip


- Remove circlip (arrow) with two screwdrivers.



A

Fig. 7 Speedometer drive

- With transmission installed, check gear oil in final drive ⇒ [page 39-1](#) .




Differential, disassembling and assembling

Note:

- ◆ Heat tapered roller bearing inner race to 100°C (212°F) before pressing on.
- ◆ Heat adjusting ring for tapered roller bearing to 100°C (212°F) before pressing in tapered roller bearing outer race.

1 - Differential housing with riveted gear for final drive

- ◆ Final drive gear is riveted onto differential housing and then machined
- ◆ If differential or final drive gear is damaged, replace differential housing along with riveted final drive gear
- ◆ Number of teeth on final drive gear \Rightarrow [from page 00-3](#), Technical data



2 - Output shaft/drive flange

- ◆ Removing and installing ⇒ [page 39-23](#)

3 - Tapered roller bearing inner race

- ◆ Pulling off ⇒ [Fig. 1](#)
- ◆ Pressing on ⇒ [Fig. 2](#)

4 - Tapered roller bearing outer race

- ◆ Remove and install only when adjusting ring heated
- ◆ Drive out with drift
- ◆ Pressing in ⇒ [Fig. 4](#)

5 - Bearing body for tapered roller bearing


- ◆ Removing and installing ⇒ [page 39-23](#), Differential, removing and installing

6 - O-ring

- ◆ Always replace

7 - O-ring

- ◆ Always replace



8 - Adjusting ring for tapered roller bearing

- ◆ Removing and installing ⇒ [page 39-23](#) , Differential, removing and installing

9 - Output shaft/drive flange

- ◆ Removing and installing ⇒ [page 39-23](#) , Differential, removing and installing

10 - Tapered roller bearing outer race


- ◆ Remove and install only when adjusting ring heated
- ◆ Drive out with drift
- ◆ Pressing in ⇒ [Fig. 4](#)

11 - Tapered roller bearing inner race

- ◆ Pulling off ⇒ [Fig. 1](#)
- ◆ Pressing on ⇒ [Fig. 2](#)

12 - Speedometer drive bushing

- ◆ Drive off together with speedometer drive gear - 13 -
- ◆ Drive on with drift



13 - Speedometer drive gear

- ◆ Drive out with drift
- ◆ Fit on together with driver bushing -item 12

14 - One-piece thrust washer

- ◆ Place into differential housing before installing bevel gears

15 - Small bevel gears

- ◆ Installing ⇒ [Fig. 3](#)


16 - Large bevel gears

- ◆ Installing ⇒ [Fig. 3](#)

17 - Circlip

CAUTION!

Do not remove the circlip until after removing the drive flange as the compression spring is pre-tensioned.




18 - Shaft for bevel gears

- ◆ Drive out with drift
- ◆ When driving in, do not damage one-piece thrust washer

19 - Spring pin


- ◆ For securing shaft for bevel gears
- ◆ Removing and installing spring pin with circumferential groove ⇒ [Fig. 5](#)



A


Fig. 1 Pulling off tapered roller bearing inner race

- Place press tool 30-555 on differential housing.



A


Fig. 2 Pressing on tapered roller bearing inner race



A

Fig. 3 Installing differential bevel gears


- Install one-piece thrust washer with gear oil.
- Install small bevel gears, drive in shaft and secure with spring pin.
- Install large bevel gears offset 180° and swivel in (in direction of arrow).



A

Fig. 4 Pressing in tapered roller bearing outer race

- With adjusting ring or bearing body heated, install outer race and press home as far as stop.



A

Fig. 5 Removing and installing spring pin with circumferential groove

- ◆ Length of spring pin: 28.5 mm (1.122 in.)

Removing

- Pull out spring pin with side-cutting pliers.

Installing

- Drive in spring pin as far as stop.